Applying a Drain Voltage to an NMOS Device

Say we apply a voltage at the **gate** of an NMOS device that is sufficiently large to **induce** a conducting channel (i.e., $v_{GS} - V_t > 0$).

Now, say that we additionally place a voltage at the NMOS drain electrode, such that:


$$V_{DS} > 0$$

where:

$$v_{DS} = v_D - v_S \doteq Drain-to-Source Voltage$$

Now guess what happens—current begins to flow through the induced channel!

Q: Current! I thought current could **not** flow because of the two p-n junctions in the NMOS device!




A: Remember, that was before we applied a sufficient gate voltage. With this voltage applied, an n-type channel is induced, forming a conducting channel from drain to source!

Recall that because of the SiO_2 layer, the gate current is zero (i.e., $i_{\varepsilon} = 0$).

Thus, all current entering the drain will exit the source. We therefore conclude that:

$$i_{S} = i_{D}$$

As a result, we refer to the channel current for NMOS devices as simply the **drain current** i_D .




Q: So, I see that you have now defined current i_D and voltages v_{GS} and v_{DS} . Just how are these parameters **related**?

A: First, we find that an increasing v_{GS} or, more specifically, an increasing excess gate voltage v_{GS} - V_t will result in a higher channel conductivity (in other words, a lower channel resistivity).

Thus, we find that the drain current i_D will increase as a positive excess gate voltage v_{GS} - V_t increases (assuming that v_{DS} >0).

This process, of increasing the induced channel conductivity by increasing the excess gate voltage, is otherwise known as channel enhancement. This is where the enhancement MOSFET gets its name!

Q: OK, but what about the relationship between drain current i_D and voltage v_{DS} ?



A: This relationship is a little complicated! Generally speaking, however, a positive v_{DS} results in a positive i_D , and the larger the v_{DS} , the larger the drain current i_D .




More specifically, we find that when v_{DS} is **small** (we'll see how small later), the drain current will be **directly proportional** to the voltage drain to source v_{DS} .

$$i_{D} \propto v_{DS}$$
 if v_{DS} small

In other words, if v_{DS} is zero, the drain current i_D is zero. Or, if the voltage v_{DS} increases by 10%, the drain current will likewise increase by 10%. Note this is just like a resistor!

$$i = \frac{v}{R}$$
 $\therefore i \propto v$

Thus, if (and only if!) v_{DS} is small, the induced channel behaves like a resistor—the current through the channel (i_D) is directly proportional to the voltage across it (v_{DS}) .




In other words, we can (for small values of v_{DS}), define a channel resistance r_{DS} :

Since
$$i_D \propto v_{DS}$$
, $\frac{v_{DS}}{i_D} \doteq r_{DS}$ (if v_{DS} small)

Note that this resistance value depends on the conductivity of the induced channel—which in turn is dependent on the excess gate voltage!

Thus, if we were to **plot** drain current i_D versus v_{DS} for various excess gate voltages, we would see something like this:



Q: Yawn! It is apparent that an NMOS transistor is so simple that virtually any intergalactic traveler should be able to understand it. It's just a voltage controlled resistor—right?

A: WRONG! Remember, channel resistance r_{DS} only has meaning if v_{DS} is small—and most often v_{DS} will not be small!

As v_{DS} increases from our presumably small value, we find that strange things start to happen in our channel!


Recall that primarily, the **free-electrons** in our inversion layer (the induced channel) were attracted to the **gate** from the heavily doped **n+ Silicon** regions under the **drain** and source.

But the **gate** now has **competition** in attracting these free electrons!

It was "easy" to attract free electrons to the gate when the gate electrode voltage was much larger than both the drain and source voltage (i.e., when $v_{GS} \gg v_{DS}$). But as the drain voltage increases, it begins to attract free electrons of its own!

Recall that **positive current entering** the drain will actually consist mainly of **free electrons exiting** the drain! As a result, the **concentration** of free-electrons in our inversion layer will begin to **decrease** in the vicinity of the **drain**.

In other words, increasing v_{DS} will result in decreasing channel conductivity!



Thus, increasing the v_{DS} will have **two effects** on the NMOS device:

- 1. Increasing v_{DS} will increase the potential difference (voltage) across the conducting channel, an effect that works to increase the drain current i_D
- 2. Increasing v_{DS} will decrease the conductivity of the induced channel, and effect that works to decrease the drain current i_D .


For small values of v_{DS} , the second effect is tiny, so that the increase in drain current is directly proportional to the increase in voltage v_{DS} (hence, we can define channel resistance r_{DS}). For example, a 10% increase in v_{DS} will result in a 10% increase in drain current.

i_D directly proportional to small v_{DS}


However, as v_{DS} increases, the **second effect** will become more and **more pronounced**. We find then that the drain current will **no longer** be directly **proportional** to the voltage v_{DS} . The reduction in channel conductivity will begin to "**counteract**" the increase in potential across the channel.

For example, a 10% increase in v_{DS} may result in only a 9% increase in i_D . Likewise, if we increase v_{DS} another 10%, the drain current may then increase only 8% (and so on).

Eventually, we find that the an increase in v_{DS} will result in **no** further increase drain current $i_D!!$ Effect 2 will **completely** "counteract" effect 1, so that there is **no more** increase in drain current as v_{DS} increases.




When this occurs, we say that we have "pinched-off" the induced channel—in other words the channel is in pinch off.



Q: So, if we continue to increase v_{DS} after the channel is "pinched off", does the drain current actually begin to decrease?

A: NO! A interesting thing happens when the channel is in pinch off. As we further increase v_{DS} , the drain current i_D will remain unchanged (approximately)! That is, the drain current will be a constant (approximately) with respect to v_{DS} .



Jim Stiles The Univ. of Kansas Dept. of EECS

Note that there are **three distinct channel conditions** in for NMOS operation.

- * Depending on the value of v_{GS} , we can have an **induced** channel, or **no** conducting channel at all!
- * Then if we have an induced channel (i.e., $v_{GS} V_{\tau} > 0$), (depending on the value of v_{DS}) the channel can be either be pinched-off or not!

Each of these three possibilities has a name—they are the names of our NMOS transistor modes!

- 1. Cutoff When $v_{GS} V_{t} < 0$, no channel is induced (no inversion layer is created), and so i_{D} =0. We call this mode CUTOFF.
- 2. Triode When an induced channel is present (i.e., $v_{GS} V_{T} > 0$), but the value of v_{DS} is **not** large enough to pinch-off this channel, the NMOS is said to be in **TRIODE** mode.
- 3. Saturation When an induced channel is present (i.e., $v_{GS} V_{\tau} > 0$), and the value of v_{DS} is large enough to pinch-off this channel, the NMOS is said to be in SATURATION mode.

We can summarize these modes in a table:

MODE	INDUCED CHANNEL?	CHANNEL PINCH-OFF?
CUTOFF	NO	N/A
TRIODE	YES	NO
SATURATION	YES	УES

